

FK02

Fitment Guide

**Each kit contains 2 x SSCR42A760-6-SB Stainless Steel Fender Mounting Poles
Rubber and Steel washers / Nuts**

- Locate and use existing fender Pole mounting hole on the truck / trailer chassis
- OR if there are no existing or correctly positioned holes on the chassis to mount to. Position the mounting pole in the required position on the chassis and mark. Using an 11/16 drill bit, drill a hole in the chassis where you have marked.
- Place the rubber washer supplied on the bolt
- From the tire side of the chassis put the bolt through the hole in the chassis.
- On the rear of the bolt positioned through the hole in the chassis, place the large steel washer onto the bolt.
- Then hand tighten the Nut onto the bolt
- Ensuring the mounting pole is in the correct position
- Proceed to tighten the nut to a recommended 89 foot pounds

