

INSTRUCTIONS: **KIENE** K-1356 Brake Drum Puller

(For use with **KIENE** K-1350 Wheel Grabber, WW2000 or WW2500 Wheel Whiz)

APPLICATION: The K-1356 is designed to remove 16-1/2" outboard brake drums.

CAUTION:

- Before using this device, read and understand these instructions.
- A complete review and understanding of the K-1350, WW2000 or WW2500 operating instructions should be made before using this device.

VEHICLE PREPARATION:

- Raise the vehicle and remove the wheel.
- Release the brakes and make certain that the brake shoes are not touching the inside of the drum

INSTALLING AND USING THE BRAKE DRUM PULLER: (Refer to the illustration below.)

- Remove the upper bolt at the Splice and loosen the lower bolt, so that the Splice can hang from the Ring.
- Install the Ring on the inboard side of the drum. Align the chain assemblies with the Wheel Grabber or Wheel Whiz eyebolts. Raise the Splice and secure it to the Ring by tightening the upper and lower bolts.
- Center the Ring on the drum using the Adjusting Screws.
- Hook the chain assemblies to the eyebolts.
- Follow the "Wheel Removal" instructions of your pulling device to finish removing the drum. Make sure that other parts of the vehicle will not interfere with the puller as the brake drum is removed.
- Loosen the wheel nuts and back them off 1-1/4".

